VELONEX

Instruction Manual
Model V-3113

560 Robert Avenue, Santa Clara, California 95050 ▪ 408-727-7370 ▪ Fax: 408-727-0389

Digitized by the Internet Archive
in 2026

https://archive.org/details/manualsplus_12385

Copyright 1992 by Velonex. No material herein may be reproduced without the written permission of Velonex.



560 Robert Avenue
Santa Clara, CA 95050
(408) 727-7370
FAX: (408) 727-0389

For additional information, please contact Velonex at the above address or the nearest Velonex representative in your area.

Serial #_____

All information contained herein is believed to be accurate and correct. However, no responsibility for errors, omissions or any problem arising by the use of this material is assumed by Velonex.

WARNING

The Model V-3113 Fast Transient Generator contains voltages which could be dangerous if contacted. All reasonable safety precautions have been taken in the design and manufacture of this instrument. DO NOT attempt to defeat the protection provided. Power should be removed and high voltage capacitors should be discharged prior to any maintenance work. Only recommended replacement parts should be used. The Model V-3113 should be operated and maintained only by personnel qualified to work with high voltage equipment.

Table of Contents

Prior to Installation 5

General Description 6

Front Panel 8

Rear Panel 11

Remote Programming 12

Operating Instructions 14

Circuit Descriptions 16

Maintenance 18

Replaceable Parts List 19

Illustrations 25

6.1A Waveshape of a Single Pulse open circuit.
6.1B Waveshape Showing Repetition Period
6.2 Not used
6.3 Not used
6.4 Functional Block Diagram
6.5 Not used
6.6 Not used
6.7 Power Supplies Schematic
6.8 Controller Card Schematic Diagram
6.8A Controller Card Circuit Schematic Diagram
6.8B Controller Card Connector Schematic Diagram
6.9 Logic Mother Board Schematic Diagram
6.9A Logic Mother Board Circuit Schematic Diagram
6.9B Logic Mother Board Connectors Schematic Diagram
6.10 Front Panel Control Board Schematic Diagram
6.10A Front Panel Board Displays Schematic Diagram
6.10B Front Panel Board Keyboard Schematic Diagram
6.10C Front Panel Board Connectors Schematic Diagram
6.11 Grid Drivers Schematic Diagram

Prior to Installation

1 Claim For Damage in Shipment This instrument should be tested as soon as possible after receipt. If it fails to operate properly, or is damaged in any way, a claim should be filed with the carrier. A full report of the damage should be obtained by the claim agent and this report should be forwarded to Velonex. We will then advise you of the disposition to be made of the equipment and arrange for repair or replacement. Include model number and serial number when referring to this instrument for any reason.

2 Warranty Velonex warrants each instrument manufactured by us to be free from defects in material and workmanship. Our liability under this warranty is limited to servicing or adjusting any instrument returned to the factory for that purpose and to replace any defective parts thereof. This warranty is effective for one year after delivery to the original purchaser when the instrument is returned, transportation charges prepaid by the original purchaser, and when upon our examination, it is disclosed to our satisfaction to be defective. If the fault has been caused by misuse or abnormal conditions or operation, repairs will be billed at cost. In this case, an estimate will be submitted before the work is started.

If any fault develops, the following steps should be taken:

1. Notify us, giving full details of the difficulty and include the model number and serial number. On receipt of this information, we will give you service data or shipping instructions.

2. On receipt of shipping instructions, forward the instrument prepaid to the factory. If requested, instrument is not covered by the warranty.

3 Shipping All shipments of Velonex instruments should be made via Air or alternately via Truck if shipping distance is under 300 miles. The instrument(s) should be either repackaged in the original shipping container or packed in a strong exterior container and surrounded by at least three inches of excelsior or similar shock absorbing material.

4 Proprietary Notice Information contained in this manual is the property of Velonex. It is issued with the understanding that none of this material may be reproduced or copied without written permission from Velonex.

Front Panel



Figure 1 V-3113 Front Panel

The following is a brief description of the V-3113 front panel controls. Please refer to Figure 1 for a visual location.

1 Power Push Button The Power Push Button is the main power switch which controls all power to the unit. As soon as the power switch is pushed, a four minute warm-up is required by the Model V-3113. A four minute counter is visible on the "Test Time" Display. During this four minute warm-up time, none of the buttons on the Model V-3113 are operable until the warm up time has expired. After four minutes, the Model V-3113 is ready for testing.

2 Ready for Test Indicator The Ready for Test Indicator is located on the front panel and is illuminated after a four minute warm up period. This light will remain illuminated until the Model V-3113 is turned off.

Note: Each time the Model V-3113 is turned-on, the ready-for-test light will take four minutes to be illuminated.

3 HV-ON Push Button The high voltage output will be turned on when the HV-ON Button has been pushed. Pressing the high voltage button while high voltage is on will turn the high voltage off.

4 One-Shot Push Button The One-Shot push button will produce a single pulse when pressed.

5 Start/Stop Push Buttons When the Green start button is pushed, continuous fast transients with the displayed PRF will appear at the output, as long as the red stop button is not pushed.

6 PRF Push Button When this button has been pressed, the frequency of the pulses can be adjusted by the select adjust knob located on the front panel. The frequency can be adjusted in steps of 0.1Hz from 1Hz to 100Hz.

7 Test Time Push Button When this button has been pressed, the test time can be adjusted with the adjust knob from 1s to 99s in steps of 0.1s.

Note: For Free Running Mode, increase the test time to more than 99s, such that no digits are visible on the test time display. Press the start button for continuous testing, then press the red stop button to stop testing at any time desired.

8 Phase Angle Push Button When in the line-sync mode and this button has been pressed, the phase angle can be adjusted with the adjust knob from the 0° to 360° in steps of 1°.

9 Select Adjust Knob This knob allows the operator to increase or decrease any variable discussed in items 6 through 9. When this knob is turned clockwise the variable will increase, and when this knob is turned counterclockwise the variable will decrease accordingly.

10 Mode Select Switch

Position 1:	Non-Sync Selects an asynchronous trigger that runs at the settings of the front panel displays. Note that the phase angle display will not come on.
Position 2:	Line Sync Selects an AC power line synchronized trigger that runs at the settings of the front panel phase angle display. The Line Sync trigger is phase synced from 0° to 360°. The AC Power line is the source for the E.U.T.
Position 3:	Programming Selects the unit for programming via the GPIB connector in the rear of the Model V-3113-S. While in this mode the unit can be addressed and controlled by a GPIB controller. The front panel controls in this mode are disable with the exception of the high voltage off button, the interlock and the power off button.

11 Scope Trigger Output A Scope Trigger is obtained by attaching a BNC Connector to the front panel. This provides a trigger pulse for oscilloscope synchronizing purposes. The Trigger is of positive polarity and approximately 5 volts. A Scope Trigger is present whenever start is on.

12 Polarity Push Button Pulse Polarity is selected via the push button located on the front panel. Two LED's are incorporated to indicate a positive or negative output.

13 Panel Meter The DPM (Digital Panel Meter) indicates the approximate peak voltage when the High voltage light is on. The meter is provided for reference purposes, and should not be used for accurate pulse measurements.

14 High-Voltage Interlock In order for high voltage to be turned on, pins 1 and 2 of connector J104 on the front panel (Figure-6.4) must be shorted together. This can easily be accomplished with plug P104 provided with the unit or an interlock cable when using the V-3113 in conjunction with a test fixture.

15 Ground Lug

16 Injection Mode Push Buttons The filter allows for three common mode tests, and one normal mode test . By pressing the two of the appropriate push button three different common modes of injection can be activated; line to ground, neutral to ground and line + neutral to ground. By pressing the appropriate push button one normal mode of injection can be activated; line to neutral.

17 Plug-In The plug-in cavity is the output for AC/Pulse events when using the internal coupler isolation network. There are different plug-in assemblies for different power configurations. The following table describes the different plug-ins and there Nema & Hubbell equivalents.

The V-3434 comes standard with the V-3113 while the V-3431 or the V-3432 must be ordered separately.

18 EUT Power On/OFF When this yellow button is pushed, a pulse (or repetitive EFT/Bursts) can be injected to the equipment under test via the AC/Pulse output connector J115 on the front panel. When the EUT power is off, the pulse is delivered through the high-voltage Pulse Output Connector. AC line Voltage: Maximum Line voltage to load, 277V RMS, 50/60Hz.

AC Line Current: Maximum continuous current to load 15A RMS.

19 Pulse Output Connectors

CAUTION: High Voltage in excess of 5kV can appear on the HN Connector. Exercise extreme caution when handling.

A HN Connector, J103 (Velonex part number, 150-0362), is used as pulse output connector and two HN Cable Assemblies (Velonex part number, 900-22089) should be used for connecting coupled transients to I/O and control lines.

A HN ground plug (P103) can be used for common mode testing of I/O and control lines. By grounding the low output the output polarity at the high output can be controlled via the front panel push button.

Floating the output connectors allow transverse injections of fast transients to I/O and control lines.

Rear Panel



Figure 2 V-3113 Rear Panel

1 EUT Power Reset A magnetic circuit breaker is located on rear panel to protect the EUT from a short circuit failure. The circuit breaker is rated for 15 amperes. If the EUT draws more than 15 amperes, the circuit breaker will create an open circuit. In this case, turn the EUT power off, remove the EUT, then flip the Circuit Breaker up into the on position for EUT power to reset.

2 EUT Power Input The EUT power input is the feed for the internal coupler/isolation network. The power applied at this input connector will be present at the front panel output cavity when the EUT POWER push button is active. The fast transient signal is attenuated at this point to prevent damage to supplementary equipment connect to the same power source that is being feed into the isolation network.

3 Line Power Cable / Fuse The three conductor power cable of the Model V-3113, ends within a polarized three prong male and female connector. Plug the female end into the Model V-3113 line filter located on the rear panel, then plug the male connector into an AC outlet.

A fuse is used to protect the instrument, and is located in the line filter. In case this fuse blows, remove the fuse and replace it with a SLO-BLO 3A 250VAC fuse. If the fuse blows again consult a qualified service personnel for a diagnosis.

4 Programming Connector
Provides a data input port with the IEEE 488 data bus.

5 Programming Address Select

Interlocks As a safety feature, the Model V-3113 incorporates active cover interlocks. For the V-3113 to operate both top and bottom interlocks must be closed.

Remote Programming

1 Remote Programming In order to begin programming the V-3113 a basic understanding of the programming theory is required. The V-3113 can be programmed through the GPIB bus(General purpose interface bus). The V-3113 will accept a string of ASCII character delimited by a carriage return. The string will be analyzed for content and an action will be taken depending on the content.

The string syntax is basically composed of three parts a mnemonic , a semicolon , and an determining value.

Ex.

AMP:2000	(1)
PRF:0150	(2)
LTG:ON	(3)

The mnemonic is a abbreviated representation of a front panel control as in example (1) AMP is an abbreviation for Amplitude, in example (2) PRF is an abbreviation for Pulse Repetition Frequency and example (3) LTG is an abbreviation for Line To Ground injection. Table 2 lists all the acceptable mnemonics.

The determining value can be either a four digit integer or a short word.

The four digit integer is superimposed on the front panel display so no decimal is required. In example (1) 2000 will display a 2000 in the amplitude display so the amplitude would be 2000 volts into an Open Circuit. Example (2) 0150 will cause 150 to be displayed in the PRF display so the output frequency would be 15.0 Hz.

The short "word" can be either ON, OFF, P or N depending of the mnemonic preceding. In example (3) the ON value will cause the output to injected onto the Line signal with respect to ground. An OFF value will turn the injection off.

Operating Instructions

1 Calibration Verification Operating Instructions

The following describes how to perform verification testing of the V-3113 fast transient generator.

CAUTION: Do not turn on high voltage until all signal connections have been made.

1. Plug the AC power cord into a 115 VAC, ± 10%, 60Hz power source.
2. Connect the Model V-3113 Scope Trigger to the External Trigger of an Oscilloscope.
3. Push the "White" power button and wait four minutes for warm-up time.
4. Select the "frequency" by pushing the frequency select push button, them adjust the frequency with the adjust knob to a value of 60Hz..
5. Select the "test" time by pushing the test time push button, then adjusting the time with the adjust knob to the continuos mode by increasing the test time value to greater than 99 seconds.
6. Connect a 100x high-voltage probe with at least a 400 MHz bandwidth to the output connector 1 (J103) through the adapter P101.
7. Ground output connector 2 (J104) with the supplied shorting plug (P103).
8. Set the Mode Select switch to the Non-Sync mode. If the Non-Sync mode is selected the phase angle will not be enabled.
9. With the "Green" ready-for-test light lit, push the HV-ON button once to turn the high-voltage on. Pressing the high-voltage button again will turn off the high voltage

Caution: Do not touch or otherwise contact the high-voltage output connector, as long as the high voltage is on!

10. Set the output Amplitude by adjusting the Amplitude adjust knob 5000 volts. The displayed value is the approximate peak value into a open circuit.
11. Set the oscilloscope to 20ns/div, 5V/div (if not using a scope which automatically compensates the scope input).
12. To initiate a pulse, press the single shot push button and view the pulse on the oscilloscope. To initiate a series of pulses continuously, press the green "start" push button.
13. Measure the peak voltage and adjust the voltage with the voltage adjust knob until the peak voltage measures 5.0 kV. The rise time should be < 10 ns (10%-90%) and the width should be >50ns (90%-90%). The decay time should be 100ns ± 50 ns (100% to 50%).
14. Stop the generator's output by simply press the red stop push button.
15. Turn the high-voltage off by pushing the HV-ON button.
16. To turn all the power off, push the Power button.

2 EUT Power Supply Testing Instructions

The following describes how to perform quality testing of EUT's power supplies installed in relay systems.

1. Connect the appropriate line power to the twist lock connector J201 located on the rear panel.
2. Plug the E.U.T.'s power cord into the Plug-In receptacle J115 on the front of the Model V-3113.
3. Press the yellow E.U.T. power to allow power to the E.U.T.
4. Turn the E.U.T. on.
5. Select the required injection mode.
6. With the various output characteristics selected press start to be testing.
7. When testing is complete, turn off the high voltage. Turn-off power to the Model V-3113.

2 Additional Caution Notes This instrument uses air convection for proper internal cooling. Do not restrict the air flow in any way.

In order to prolong the life of the components within the Model V-3113, turn the high-voltage off when the instrument is not in use. The instrument should not be left operating with a continuous trigger when not required.

Circuit Descriptions

1 . General Information The Velonex Model V-3113 is a Thyratron based design that incorporates a built-in coupler/isolation network for line injection. The Model V-3113 uses circuitry to determine the pulse width, rise and decay times. The PRF, burst duration, burst period, phase angle and test time are fully microcomputer controlled. The selection of each parameter can be selected by front panel push buttons (See Figure-4). The pulse switching networks of the generator are not field serviceable. Schematic diagrams of these parts are not included. If any problem arises, please contact Velonex.

2 Power-On Circuits When the Power switch (S118) closes, transformers T201, T202, T401 and T402 are energized. With the power on fans B201, B202 and B401 are energized. Line filter FL201 contains the power fuse for the unit and also act as a low pass filter to filter out high frequency noise on the AC power lines. MOV's RV401 - RV404 are utilized to suppress any power surges which might be exposed to the unit.

3 GRIDS Drive Circuitry To achieve full performance capability of the Thyratron, the drive pulses should be optimum. GRID 1 is driven by one mosfet device. A TTL level signal , trigger 1, drives Z601A which in turn drives Z602A. Transformer T601 is a pulse transformer that is used to isolate the TTL level voltage from the 800 volts supply. The peak GRID 1 output voltage is about 800 volts. GRID 2 is also driven by one mosfet device. TRIG2, a TTL level trigger, drives Z601B and in turn drives Z602B. Transformers T601B is used to isolate the TTL level voltage from the 800 volt supply. The peak GRID 2 output voltage is also about 800V. A negative bias of 100 volts sits below the 800 volt grid 2 pulse to hold off the thyratron anode voltage. The GRID 2 trigger pulse is delayed relative to GRID 1 pulse to allow the discharge to become established.

4 HV-ON Circuitry When the HV-ON momentary switch S101 is pressed, relay K401 will activate providing DC power to HV DC to DC converters PS1601 and PS202. PS1601 is controlled via a 0 - 5V signal generated by Z2401 D/A converter. PS1601 supplies the Thyratrons anode voltage which is directly proportional to the output voltage. Capacitor C1601 store the energy for the burst of output pulses. PS202 provides the 800 V requied for the grid pulses. Capacitors C512-C515 store the energy required for the grid pulses.

5 Power Supplies The Model V-3113 uses seven DC power supplies:

1. A 6.3V power supply for the cathode heater. This power supply is regulated through transformers T201, CR201, C201 and R201.

2. A 5.3VDC power supply for the reservoir heater of the Thyratron. This power supply is regulated, positive 5.3 volts DC source employing IC regulator Z401 and associated components T1102, CR401, C401, R401, R402, R403, and C402.

3. A 7.5kV power supply for the anode voltage supply. This power supply is a regulated positive 7.5kV 10mA DC source.

4. A 800V power supply for the GRID Trigger supply. This power supply is a regulated positive 800 volt DC source.

5. A 30V power supply for the power control relay circuitry. This power supply is an unregulated positive 30 volt DC source utilizing T202, CR202, and capacitors C402-C407.

6. A 18V power supply for the mosfet driver supply. This power supply is regulated, positive 18 volt DC source employing IC regulator Z403 and capacitor C413.

7. A 24V power supply for the front panel power lights and opto-isolation circuit. This power supply is regulated, positive 24 volt DC source employing IC regulator Z404 and and capacitor C409.

8. A 5.0VDC power supply for the control logic. This power supply is regulated, employing a voltage requlator Z407 and capacitor C413.

9. A -100VDC power supply for the GRID 2 bias of the Thyratron. This power supply is aregulated negative 100 volt DC source employing IC regulator Z406 and associated components T402, CR404, C414, R406, R407, R408,R409 and C415.

6 Coupler/Isolation Filter Section Refer to Figure-10 for the following circuit description. The coupler/isolation filter employs ceramic vacuum relays for

switching the surge injection and polarity. Depending on the front panel selected injection mode, the appropriate relay is activated by the microcontroller circuitry. K801 through K804 are used for injection modes and to direct the pulse to the HV output connectors J101 and J103. Pulse polarity can be controlled by grounding of the two output connectors with the ground plug provided with the unit. Relays K805 and K806 are used to couple the pulses through coupling capacitor networks (CN801 and CN802). Inductors L1001 and L1002 are used to block the pulses from being injected into the AC mains while allowing the AC power to get to the E.U.T. After the EUT AC power has been connected to J201, relays K201 and K202 switche the electrical connection from J201 to the coupler/isolation network. CB201 is a magnetic circuit breakers which limit the network current to 15A because of thermal heating in the isolation network. At J115, the E.U.T. is exposed to the AC power and the output pulse.

7 Thyratron and Pulse Forming Circuit These are not shown. Please see explanation in Section 3.1.

8 Digital Control Circuit The digital control circuits are comprised of these sections: the controller card (Figure-8), the logic mother board (Figure-9), the front panel board (Figure-10). The controller card's main function are reading the front panel push buttons, determining the required action, setting timing chips and relays to appropriate value and lastly updating the displays. The mother boards primary function is power distribution, signal routing, relay driving and trigger driving. The front panel board's primary function is refreshing discrete LED's, opto-coupling the push buttons to the logic supply level and creating the trigger pulse output.

9 Controller Card The controller card is controlled centrally by a micro-controller U1405 which contains the system software. The micro-controller accessed other chips using port C and U1413. Data from the front panel keyboard matrix is stored in U1414 and is read by U1405 after U1414 interrupts signaling a change on the front panel. U1407 and U1411 are timer chips which control the timing and are always running. U1406 sends data to control the output for either non-synchronized or line synchronized output, one shot, starting and stopping, and also HV-ON. The trigger output from U1401 goes to U1412 where it is gated by U1406. The signal from U1412 feeds from U1403B which drives the scope trigger and the grid driver circuits. U1401 and U1404 are decoding chips which read the data from R101, a digital pot, and translates it to a parallel out where U1405 (the micro-controller) can read the data. U1402 is a comparator which is used for the zero-crossing circuit which is fed to U1407 for line synchronization.

10 Logic Mother Board The logic mother board has multifunctions. Circuit designations U1301 and U1302A are used for creating a delay time between grid 1 and grid 2. U1307 and U1308 are outputs which drives the grid driver board on Figure-11. U1303, U1304, U1305 and U1306 are used to drive the instrument relays and there outputs are designated on the right side of the schematic. Connector J1301 and J1302 are in parallel for an additional plug-in card. J1303 and J1304 are for power distribution. J1302 and J1303 are for signal connections between the logic mother board and the front panel board.

11 Front Panel Board The front panel board has three main functions. The LED display are driven from the serial output from the controller card. Each chip, U1802-U1806, individually drives each display D1801-D1805. U1801 drives all the discrete LED's as directed by the controller card. The signals front the logic mother board which control the front panel lights are routed on this board for easy termination Z1801-Z1803 are opto-couplers which connect the front switches to the controller card. R101, the digital pot on the front panel, is plugged into connectors J1804 and J1805 where the signal is sent to the controller card. Q1801 and T1801 comprise the scope trigger function which has an isolated output.

Maintenance

1 Servicing Before attempting to service this instrument, study the circuit descriptions of Section 3.

2 Cooling The Model V-3113 utilizes convection cooling. A vent is on the bottom of the cabinet, the bottom and rear of the cabinet must be clear of obstructions.

3 Cabinet Removal Remove the four screws from the front panel (two on each side), and the four screws (two on each side) holding the rear mounting brackets to the chassis. Slide the instrument forward to clear the cabinet.

4 Top Cover Removal Remove the sixteen flathead screws. Removal of the top cover opens interlock switch S202.

5 Bottom Cover Removal Remove the sixteen flathead screws. Removal of the bottom cover opens interlock switch S201.

6 Cleaning Periodically inspect the instrument for dust accumulation. Clean with a vacuum cleaner or dry air under moderate pressure.

7 Panel Lights The Panel Lights; POWER ON, READY FOR TEST, and HV-ON, are replaceable from the front panel by snapping out the translucent cover from each light. Chicago miniature number 327, 28 volt bulbs are used. If any indicator light becomes dim, replace it to prevent the possibility of having high-voltage on in the absence of the red indicator lights. Panel lamp replacement may be facilitated by the use of a lamp tool (Microswitch type 15PA19 tool is recommended).

8 Fuse and Circuit Breakers A fuse is used to protect the instrument. The fuse is located on the rear panel of the instrument rated at 3 amps. In case this fuse blows, remove the fuse and replace it with a SLO-BLO 3A 250VAC fuse. If the fuse blows again consult a qualified service personnel for a diagnosis.

9 Interlocks Two interlocks are provided for safety, one on each of the chassis top and bottom covers.

10 Instrument Failure By carefully observing the symptoms and by referring to the schematic diagrams, most problems can be pinpointed quickly to a particular circuit. If a problem can't be solved, call the Velonex service department. Do not ship an instrument back without a Return Merchandise Authorization (RMA) number.

VELONEX

560 Robert Avenue
Santa Clara, CA 95050
(408) 727-7370
FAX: (408) 727-0389

Replaceable Parts List

The following lists the replaceable parts used in the Model V-3113 Surge Transient Generator. Circuit reference designations, where applicable, refer to the schematic diagrams in Section 6. Replacement parts should be ordered by specifying the entire Velonex part number.

1 Sub-Assemblies: (Unless otherwise specified all resistors are in ohms, 1/4 watt, +5%.)

STOCK #	DESCRIPITION	CIRCUIT DESIGNATION
900-PP60	ASSY, 650-1000 VDC HV PWR SP	PS202
900-21267	ASSY, CONTROLLER CARD	1400 SERIES
900-21236	ASSY, COUPLING INDUCTOR	L1001,L1002
900-21308	ASSY, FET TRIGGER BOARD	600 SERIES
900-21450	ASSY, FILTER BRD	1000 SERIES
900-21406	ASSY, FRONT PANEL	100 SERIES
900-21457	ASSY, FRONT PANEL CONTROL BRD	1800 SERIES
900-21353	ASSY, GROUND STRAP	200 SERIES
900-21247	ASSY, INDUCTOR CHARGING NETWRK	900 SERIES
900-21503	ASSY, LO VOLTGE POWER SUPPLIES	400 SERIES
900-21633	ASSY, LOGIC MOTHER BOARD	1300 SERIES
900-21340	ASSY, OPTION "S" PROGRAMMING	2300 SERIES
900-21369	ASSY, PROGRAMMING CARD	2400 SERIES
900-21369	ASSY, PROGRAMMING CARD	2400 SERIES
900-21235	ASSY, TRANSFORMER BOARD	1700 SERIES
900-21638	ASSY,FAN	B201
900-21553	ASSY,HV METER DISPLAY	M101
900-21196	ASSY,PLUG IN	100 SERIES

2 Resistors: (Unless otherwise specified all resistors are in ohms, 1/4 watt, +5%.)

STOCK #	DESCRIPITION	CIRCUIT DESIGNATION
094-0098	POTENTIOMETER, DIGITAL	R101, R102
091-0020.071	RES FIX COMP, 2.2K, 2W	R103-106(RN101,102)
091-0012.015	RES-CARB-COMP 10 OHMS, 1/2W	R301
091-0020.135	RES-CARB-COMP 1M OHM, 2W	R302-313
091-0020.103	RES-CARB-COMP, 47K, 2W	R401
091-0008.071	RES-CARB-COMP, 2.2K, 5%, 1/4W	R402
094-0094	POT, 1M	R403
091-0012.104	RES-CARB-COMP, 51K, 1/2W	R404, R407
091-0008.042	RES-CARB-COMP 130, 5%, 1/4W	R405
094-0102	POT, 2K, 1/4W	R406
091-0008.069	RES-CARB-COMP, 1.8K, 5%, 1/4W	R408
094-0115	POT, 200K, 1/4W	R409
091-0020.038	RES-CARB-COMP, 91, 2W	R410
092-0016	RES,WW,8K,5%,5W	R411
092-0031	RES-FIX-WW, 5KOHM, 14.5W	R501, R523
091-0020.047	RES-CARB-COMP, 220 OHM, 2W	R510-520*
091-0020.063	RES-CARB-COMP, 1K OHM, 2W	R521,R522
091-0020.078	RES-CARB-COMP, 4.3K OHM, 2W	R524-527*, R502-509*
091-0020.056	RES-CARB-COMP, 510 OHM, 2W	R528-532*
093-0097	RES-SMD, 75 OHMS, 1%	R601-603
091-0020.027	RES-FIX-COMP, 33 OHM, 2W, 5%	R701-R708
091-0020.024	RES-FIX-COMP, 24 OHM, 2W, 5%	R709-R711
091-0020.084	RES-CARB-COMP, 7.5K OHMS, 2W	R901-911
094-0112	RES-WW, 2 OHM, 10W, 5%	R1101
091-0008.039	RES-CARB-COMP, 100, 1/4W	R1301
091-0008.056	RES-CARB-COMP, 510, 1/4W	R1302
094-0101	TRIM POT, 50K	R1303
094-0104	RES-VAR-TRIMPOT, 1K	R1304
091-0008.111	RES-COMP, 100K, 1/4W	R1401
091-0008.079	RES-COMP, 4.7K, 1/4W	R1402, 1405
091-0008.087	RES-COMP, 10K, 1/4W	R1403, 1404, 1411
091-0008.105	RES-COMP, 56K, 1/4W	R1406
091-0008.056	RES-COMP, 510, 1/4W	R1407
091-0008.075	RES-COMP, 3.3K, 1/4W	R1408
091-0008.133	RES-COMP, 820K, 1/4W	R1409
091-0020.015	RES-CARB-COMP, 10OHMS, 2W	R1601
091-0020.135	RES-CARB-COMP, 1MOHM, 2W	R1602-1605
091-0008.075	RES-CARB-COMP 3.3K, 5%, 1/4W	R1801,1802,1807,1816,1826
091-0008.039	RES-CARB-COMP, 100, 5%, 1/4W	R1803-1806
091-0008.062	RES-CARB-COMP, 910, 5%, 1/4W	R1808-1811
091-0008.087	RES-CARB-COMP 10K, 5%, 1/4W	R1812-1815
091-0008.065	RES-CARB-COMP, 1.2K, 5%, 1/4W	R1817-1820, 1827
091-0008.047	RES-CARB-COMP 220, 5%, 1/4W	R1821,1822,1828-1832
091-0008.032	RES-CARB-COMP 51, 5%, 1/4W	R1824
091-0008.036	RES-CARB-COMP 75, 5%, 1/4W	R1825
091-0008-063	RES-CARB-COMP 1K, 5%, 1/4W	R1833, R1823
091-0008.051	RES-CARB-COMP 330, 5%, 1/4W	R1834
091-0008.055	RES-CARB-COMP 470, 5%, 1/4W	R1835
091-0016.099	RES-CARB-COMP, 33K, 1W	R1901
094-0093	POTENTIOMETER, 50K	R1902
091-0020.135	RES-CARB-COMP, 1M, 2W	R1903-1912
093-0075	RES-CARB-COMP, 1M, SMD	R2301
093-0094	RES-CARB-COMP, 10K, SMD	R2302
091-0008.094	RES, COMP, 20K, 1/4W, 5%	R2401
091-0008.087	RES, COMP, 10K, 1/4W, 5%	R2402
	RESISTOR PACK	RP2301

2 Capacitors: (All values in æf, +20%, except where otherwise noted.)

STOCK #	DESCRIPITION	CIRCUIT DESIGNATION
102-0020	CAP-FOIL, 400V, .22	C1001,1002
101-0055	CAP FIX CERM 10PF, 1KV, 10%	C101-104 (CN101,102)
102-0095	CAP-EXT-FOIL, 0.5uF, 1000VDC	C301, 302
105-0124	CAP-LYTIC, 1000uF, 35V	C401, 402, 407
105-0132	CAP-LYTIC, 470uF, 63V	C403, 404
105-0059	CAP, ELECT, 250uF, 150V	C405, 406
105-0136	CAP FIX LYTIC 330000 MFD,15VDC	C408
102-0087	CAP-FOIL, 0.1uF, 1KV	C501, C507, C514
103-0026	CAP-MICA, 500pF, 1500V	C508-512*
103-0023	CAP-MICA, 250pF, 1500V	C513*
101-0002.029	CAP-CER, 0.05uF, 500V, 20%	C515,516*
101-0074	CAP-CER, 1uF, 50V	C601, 604, 605, 608
101-0075	CAP-CER, 0.1uF, 50V	C602, 603, 606, 607
105-0108	CAP-LYTIC, 22uF, 63V	C609-612
103-0031	MICA-CER, 20pF, 3kV, 5%	C701
101-0077	CAP-CER, 470 pF, 10kV	C703, C704, C705
101-0005	CAPACITOR, 0.01uF, 3KV	C801-806*
105-0133	CAP-LYTIC, 1000uF, 63V	C1101-1102
103-0001.027	CAP, MICA, 100pF, 500V	C1301-1303, C1310
101-0047	CAP,CERAMIC, 0.1uF, 50V	C1304-1308,C1311,C1313-131
105-0122	CAP-LYTIC, 100uF, 16V	C1309
105-0137	CAP-FIX-LYTIC, 100uF, 50V	C1312
105-0108	CAP-FIX-LYTIC, 22uF, 63V	C1315
101-0066	CAP-CER, 0.01uF, 50V	C1401-5,8,9,11-15,17,19-25,27
104-0006.039	CAP-TANT, 6.8uF, 35V	C1406,1407,1426
101-0047	CAP-CER, 0.1uF, 50V	C1416
106-0020	CAP-FIX-OIL, 0.5uF, 3000VDC	C1601
106-0060	CAP-FIX-OIL, 2.0uF, 7.5KV	C1602
101-0066	CAP,CERAMIC, 0.01UF, 50V	C1801-1808,C1810-1811
103-0001.035	CAP-FIX-MICA 220 PF, 500V	C1809
104-0031	CAP-CER, 0.01uF, SMD	C2301, C2102, C2304, C2305
104-0029	CAP-TANT, 6.8uF, SMD	C2303, C2306
101-0066	CAP, CER 0.01uF, 50V	C2401-C2402
104-0006.039	CAP, TANT, 6.8uF, 35V	C2403

3 Diodes:

STOCK #	DESCRIPITION	CIRCUIT DESIGNATION
111-0197	LED, GREEN "START"	CR101
111-0198	LED, YELLOW, INJECTION MODE	CR102, 103, 104
111-0192	LEDS, AMBER DIFFUSED	CR105, 106
111-0069	DIODE, BRIDGE	CR401,402
111-0127	DIODE, 4kV, 250mA	CR701, CR702
111-0214	DIODE, FAST RECOVERY	CR801-812
111-0219	DIODE, ULTRA-FAST 1000V	CR813-816
111-0003	DIODE, SIGNAL	CR1401,1402
111-0062	DIODE, SILICON 1A 200V	CR1501
111-0127	DIODE	CR1601-1604
111-0003	DIODE	CR1801

4 Transistors:

STOCK #	DESCRIPITION	CIRCUIT DESIGNATION
112-0151	TRANSISTOR	Q601
112-0150	TRANSISTOR	Q602
112-0001	TRANSISTOR, NPN	Q1801

5 Switches:

STOCK #	DESCRIPITION	CIRCUIT DESIGNATION
131-0003	SWITCH, DPDT MOMENT	S101, 102
131-0103	SWITCH, PUSH BTTN, SPDT MOMENT	S103-106,109-112,114,116
131-0105	SWITCH, SP3T	S107, 108, 117
131-0006	INTERLOCKS, TOP & BOTTOM	S201, S202
131-0001	SWITCH, DPDT, POWER	S118
131-0122	DIP SWITCH	S2301

6 Transformers:

STOCK #	DESCRIPITION	CIRCUIT DESIGNATION
900-21545	XFMR, 12V @ 8A ASSY	T201/P402
900-21546	XFMR, 100VA, 115/230 PRI	T202/P403
900-21333	TRANSFORMER, PULSE	T601
900-21429**	BROAD BAND TRANSFORMER	T801
142-0140	XFMR, 60V, .16ASEC, 115/230PRI	T1101
142-0146	XFMR, 8.0V, 1.25ASEC, 115/230P	T1102
142-0014	TRANSFORMER,110/220 - 12/14	T1701
900-3349	TRANSFORMER,PULSE	T1801

7 Panel Lamps:

STOCK #	DESCRIPITION	CIRCUIT DESIGNATION
280-0009	LAMPS, 28V, 0.04A	I101-108

8 Integrated Circuits:

STOCK #	DESCRIPITION	CIRCUIT DESIGNATION
113-0096	IC,DUAL MONOSTABLE	U1301
113-0104	IC, HEX INVERTER	U1302, U1309
113-0119	IC,RELAY DRIVER,4A,80V	U1303-1304,U1306
113-0165	IC,OCTAL 3-STATE LATCH	U1305
113-0150	IC,FET DRIVER,6A PK	U1307-1308
113-0181	REGULATOR +12V	U1310
113-0122	IC, HP QUAD DEC/CT, 16 PIN	U1401,1404
113-0097	IC, COMPARATOR	U1402
113-0096	IC, MONOSTABLE, 16 PIN	U1403
113-0171	MICROCONTROLLER, 8 BIT, 40 PIN	U1405
113-0165	IC, HEX, 3-STATE LATCH, 20 PIN	U1406
113-0169	IC,COUNTER/TIMER, 10MHZ, 24PIN	U1407,1411
113-0116	IC, HEX INVERTER, 14 PIN	U1408, 1409
113-0100	IC, QUAD OR GATES, 14 PIN	U1410
113-0095	IC, QUAD AND GATES, 14 PIN	U1412
113-0118	IC, 8-BIT DECODER, 16 PIN	U1413
113-0170	IC,KEYBOARD/DISPLAY INT,40 PIN	U1414
113-0165	OCTAL, 3 STATE LATCH	U1801
113-0153	IC,MULTIPLE LED DISPLAY DRIVER	U1802,U1805,U1806
113-0174	IC, GPIB INTERFACE, SMD	U2301
113-0175	IC, INTERFACE TRANCEIVER, SMD	U2302
113-0176	IC, INTERFACE TRANCEIVER, SMD	U2303
113-0177	IC, DATA BUFFER, SMD	U2304
113-0178	IC, HCMOS I/O BUFFER	U2401
113-0116	IC, INVERTER, 14 PIN	U2402
113-0167	IC,CRYSTAL OSCILLATOR TTL,2MHZ	X1401
113-0168	IC,CRYSTAL OSCILLATR TTL,10MHZ	X1402
113-0167	CRYSTAL OSCILLATOR TTL, 2MHZ	X2301
113-0154	REGULATOR	Z401
113-0101	REGULATOR	Z402
113-0155	REGULATOR	Z403
113-0172	IC, SMD, CMOS PWR MOSFET DRIVR	Z601
113-0156	IC, QUAD OPTO-ISOLATOR	Z1801-1803
113-0179	IC, 8-BIT D/A	Z2401
113-0131	IC, OP-AMP	Z2402

9 Relays:

STOCK #	DESCRIPITION	CIRCUIT DESIGNATION
132-0070	RELAY, HIGH CURRENT 40A	K201,K202
132-0068	RELAY, SPDT, 5KV, 26.5V	K801-804
132-0044	RELAY, SPST, NC, 10KV, 26.5V	K805-806

10 Inductors:

STOCK #	DESCRIPITION	CIRCUIT DESIGNATION
142-0143	INDUCTOR, 4H, 90mA	L901
141-0031	INDUCTOR, 390uH, +/- 10%, SMD	L2301
037-0033	INDUCTOR NETWORK	LN201, LN202
037-0033	INDUCTOR NETWORK	LN701 - LN704
037-0037	INDUCTOR NETWORK	LN801, LN802

11 Miscellaneous:

STOCK #	DESCRIPITION	CIRCUIT DESIGNATION
270-0039	CIRCUIT BREAKER, 277VAC, 15A	CB201
150-0034.001	GROUND POST	
150-0034.002	GROUND, KNURL NUT	
170-0068	HANDLE 7 INCH	
V-3379	PLUG, 125V, 15A, 3 PRONG	
V--3431	PLUG, 240V, 15A	
V-3378	PLUG, 277V, 15A,	
053-0008	POWER CORD, 125V, 10A	
IM-223	V-3113 INSTRUCTION MANUAL	
280-0009	LAMPS, 28V, 0.04A	I101-108
150-0335	CONNECTOR, HN	J101, J103
150-0098	BNC CONNECTOR	J102
150-0345	CONNECTOR, MINIATURE RECEPTCLE	J104
150-0325	FLANGED INLET	J201
150-0362	HV OUTPUT CONNECTOR	P101
900-21458	SHORTING PLUG	P103
900-21628	PLUG,FEMALE MICROPHONE	P104
150-0323	CONNECTOR, 227V, 15A	P203

Illustrations



WAVESHAPE OF A SINGLE PULSE OPEN CIRCUIT
FIGURE 6.1A



WAVESHAPE SHOWING REPETITION PERIOD
FIGURE 6.1B



MODEL V-3113
FIGURE-6.2
FRONT PANEL CONTROLS

3/91



VELONEX
MODEL V-3113
REAR CHASSIS DISPLAY
FIGURE 6-3



MODEL V-3113
FIGURE 6-4
FUNCTIONAL BLOCK DIAGRAM

3/91



NOTES:

1. UNLESS OTHERWISE SPECIFIED, ALL RESISTORS ARE IN OHMS 1/4W +/-5%.

2. UNLESS OTHERWISE SPECIFIED, ALL CAPACITORS ARE IN MICROFARADS.

VELONEX

POWER SUPPLIES

SCHEMATIC DIAGRAM

MODEL V-3113

Figure 6-5

3113_5.SCH 7/92

FIGURE-6A

V3113 CONTROL BOARD LOGIC

FIGURE-6B

V3113 CONTROL BOARD CONNECTOR



VELONEX

MODEL V-3113

CONTROLLER CARD
SCHEMATIC DIAGRAM

FIGURE 6-6

3113_6.SCH 7/91


+5VDC
R1 100K
R6 56K
R5 4.7K
R3 10K
R2 4.7K
R4 10K
CR2
CR1
C3 0.01
C7 6.8
HSYNC
FIGURE 6B
LSYNC
FIGURE 6B
U2
U8B
U9C
X1 OUT 2MHz
X2 OUT 10MHz
U7
U11
U6
U14
U5
U10A
U10B
U8A
U9A
U12B
U9F
U12A
U1
U4
CH A
CH B
RST
OE
SEL
CLK
POT1A
POT1B
POT2A
POT2B
C2 0.01
C1 0.01
C13 0.01
C12 0.01
U3B
U3A
CEXT
REXT/CEXT
CLR
R7 510
C9 0.01
R8 3.3K
TRG
SCPTRG
FIGURE 7A
FIGURE 6B
R9 820K
C15 0.01
C16 0.1
C8 0.01
RESET
IRQ
TCAP
OSC1
OSC2
PA0
PA1
PA2
PA3
PA4
PA5
PA6
PA7
PB0
PB1
PB2
PB3
PB4
PB5
PB6
PB7
PC0
PC1
PC2
PC3
PC4
PC5
PC6
PC7
PD0/RDI
PD1/TDO
PD2/MISO
PD3/MOSI
PD4/SCK
PD5/SS
TCMP
PD7
A[0..7]
D[0..7]
B[0..9]
C[0..16]
U9D
U13
U9C
U10C
R11 10K
IRQ
C2
Q[2..7]
AL[0..7]
SL[0..3]
OA[0..7]
NOTES:
1. ALL CIRCUIT DESIGNATIONS ARE 1400 SERIES
2. UNLESS OTHERWISE SPECIFIED ALL RESISTORS ARE 1/4, 5% IN OHMS.
3. UNLESS OTHERWISE SPECIFIED ALL CAPACITORS ARE IN MICROFARADS.
VELONEX
MODEL V-3113
CONTROLLER CARD CIRCUIT SCHEMATIC DIAGRAM
FIGURE 6-6A
3113_6A.SCH 7/91



NOTE:
1.ALL CIRCUIT DESIGNATIONS ARE 1400 SERIES.

2.UNLESS OTHERWISE SPECIFIED ALL RESISTORS ARE 1/4W, 5% IN OHMS.

3.UNLESS OTHERWISE SPECIFIED ALL CAPACITORS ARE 20% IN MICROFARADS.

VELONEX

MODEL V-3113

CONTROL CARD CONNECTOR SCHEMATIC DIAGRAM

FIGURE 6-68

3113_6B.SCH 7/91

FIGURE-7A

LOGIC MOTHER BOARD CIRCUIT



FIGURE-7B

LOGIC MOTHER BOARD CONNECTORS



VELONEX

MODEL V-3113

LOGIC MOTHER BOARD
SCHEMATIC DIAGRAM

FIGURE 6-7

3113_7.SCH 7/91

+5VDC
TO J405/7
FIGURE 5
JP1303A
R1301
100
R1303
50K
C1301
100pF
U1301A
CEXT
REXT/CEXT
A
B
CLR
Q
74HC123
GND
TO J405/12
FIGURE 5
JP1303B
+5VDC
R1302
510
C1302
0.01uf
U1301B
U1307
TSC429L
J1307A
TRIG-2
TO J501/4
FIGURE 9
J1307B
GND
TRG
FIGURE 6A
U1302A
74HC04
U1308
TSC429L
J1307C
TRIG-1
TO J501/3
FIGURE 9
J1307D
GND
Q[2..7]
FIGURE 6A
Q[3..7]
Q3
Q4
U1302B
74HC04
U1303
UDN2798
B1
B2
B3
B4
C1
C2
C3
C4
ADYLGHT
TO 1814, FIGURE 8A
HVLGHT
TO 1819, "
HVPWR
J405/3
TO FIGURE 5
JP1301N
JP13010
JP1305B
B[0..7]
FIGURE 6A
B[0..7]
Q5
U1302C
74HC04
Q6
U1302D
74HC04
Q711
U1302E
74HC04
U1304
UDN2798
JP1306
POSPOL
NEGPOL
L2G
N2G
RLY4
RLY3
RLY2
RLY1
TO P801/3, FIGURE 10
TO P801/4, "
TO P801/5, "
TO P801/6, "
JP1305C
JP1305D
JP1305E
JP1305F
+30VDC
JP1305K
JP1305L
+30VDC
TO K201/86, FIGURE 10
TO P801/12, "
U1305
74HC373
B0
B1
B2
B3
B4
B5
B6
B7
D0
D1
D2
D3
D4
D5
D6
D7
Q0
Q1
Q2
Q3
Q4
Q5
Q6
Q7
OC
G
QA0
QA1
QA2
QA3
U1306
UDN2798
L2N
EUTLGHT
OUTSEL
EUTPWR
RLY5
RLY6
TO P801/7, "
TO 1820, FIGURE 8A
TO P801/9, FIGURE 10
TO K202/85, "
JP1305G
JP1301P
JP1305I
JP1305J
C15
FIGURE 6A
U1302F
74HC04
C1303
0.01
+5VDC
C1309
100
C1304
0.1
C1305
0.1
C1306
0.1
C1307
0.1
C1308
0.1

NOTES:
1.UNLESS OTHERWISE SPECIFIED ALL RESISTORS ARE 1/4W, 5%, IN OHMS.

2.UNLESS OTHERWISE SPECIFIED ALL CAPACITORS ARE 20% IN MICROFARDS

3.JUMPER IN POSITION "A" FOR V-3300 AND POSITION "B" FOR V-3113.

VELONEX

MODEL V-3113

LOGIC MOTHER BOARD CIRCUIT SCHEMATIC DIAGRAM

FIGURE 6-7A

3113_7A.SCH 10/92


J1302
+5VDC
A0 A1 A2 A3 A4 A5 A6 A7 B0 B1 B2 B3 B4 B5 B6 B7 C0 C1 C2 C3 C4 C5 C6 C7 C15 C16 D0 D1 D2 D3 D4 D5 D6 D7
HSYNC LSYNC TRG SCPTRG POT1A POT1B POT2A POT2B Q2 Q3 Q4 Q5 Q6 Q7 AL0 AL1 AL2 AL3 AL4 AL5 AL6 AL7 SL0 SL1 SL2 SL3 OA0 OA1 OA2 OA3 OA4 OA5 OA6 OA7
CONNECTOR EDGE72


IRQ
J1301
+5VDC
A0 A1 A2 A3 A4 A5 A6 A7 B0 B1 B2 B3 B4 B5 B6 B7 C0 C1 C2 C3 C4 C5 C6 C7 C15 C16 D0 D1 D2 D3 D4 D5 D6 D7
HSYNC LSYNC TRG SCPTRG POT1A POT1B POT2A POT2B Q2 Q3 Q4 Q5 Q6 Q7 AL0 AL1 AL2 AL3 AL4 AL5 AL6 AL7 SL0 SL1 SL2 SL3 OA0 OA1 OA2 OA3 OA4 OA5 OA6 OA7
CONNECTOR EDGE72









TO FIGURE-10C


JP1301
AL0 AL1 AL2 AL3 AL4 AL5 AL6 AL7 POT1A POT1B POT2A POT2B RDYLGHT HVLGHT EDTLGHT A4 A5 A6 A7
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20
HEADER 20

TO FIGURE-10C



VELONEX

MODEL V-3113

LOGIC MOTHER BOARD CONNECTORS
SCHEMATIC DIAGRAM

FIGURE 6-7B

3113_7B.SCH 7/91

FIGURE-8A

FRONT PANEL BOARD DISPLAYS

A [4..7]

D [0..7]

RL [0..7]

SL [0..3]

OA [0..7]

POT1A

POT1B

POT2A

POT2B

SCPTRG

FIGURE-8B

FRONT PANEL BOARD KEYBOARD

D [0..7]

RL [0..7]

SL [0..3]

OA [0..7]

POT1A

POT1B

POT2A

POT2B

SCPTRG

FIGURE-8C

FRONT PANEL BOARD CONNECTOR

A [4..7]

D [0..7]

RL [0..7]

SL [0..3]

OA [0..7]

POT1A

POT1B

POT2A

POT2B

SCPTRG

VELONEX

MODEL V-3113

FRONT PANEL BOARD
SCHEMATIC DIAGRAM

FIGURE 6-8

3113_8.SCH 7/91



NOTES:
1.UNLESS OTHERWISE SPECIFIED ALL RESISTORS ARE 1/4W, 5%, IN OHMS.

2.UNLESS OTHERWISE SPECIFIED ALL CAPACITORS ARE 20% IN MICROFARADS.

VELONEX

MODEL V-3113

FRONT PANEL BOARD DISPLAYS SCHEMATIC DIAGRAM

FIGURE 6-8A

3113_8A.SCH 10/92



NOTES:
1. UNLESS OTHERWISE SPECIFIED ALL RESISTORS ARE 1/4W, 5%, IN OHMS.

2. UNLESS OTHERWISE SPECIFIED ALL CAPACITORS ARE 20% IN MICROFARADS.

VELONEX

MODEL V-3113

FRONT PANEL BOARD KEYBOARD SCHEMATIC DIAGRAM

FIGURE 6-88

3113_88.SCH 7/91



NOTES:
1.UNLESS OTHERWISE SPECIFIED ALL RESISTORS ARE 1/4W, 5%, IN OHMS.

2.UNLESS OTHERWISE SPECIFIED ALL CAPACITORS ARE 20% IN MICROFARADS.

VELONEX

MODEL V-3113

FRONT PANEL BOARD CONNECTORS SCHEMATIC DIAGRAM

FIGURE 6-8C

3113_8C.SCH 7/91



NOTES:

1. UNLESS OTHERWISE SPECIFIED, ALL RESISTORS ARE 2W IN OHMS.
2. UNLESS OTHERWISE SPECIFIED, ALL CAPACITORS ARE IN MICROFARADS
3. Z601 POWER PINS 1 & 8 : GND PINS 4 & 5.
4. +24VDC, +800VDC AND -130VDC ARE FROM FIG-7.

VELONEX

MODEL V-3113

GRID DRIVERS
SCHEMATIC DIAGRAM

FIGURE 6-9

3113_9.SCH 10/92

DISCHARGE CIRCUIT

ALL ITEMS ARE NOT INCLUDED IN THE REPLACEABLE PARTS LIST

ASSY: BV-21247 (900)

ASSY: CV-21384 (700)

ASSY: DV-21421 (800)

ASSY: BV-21450 (1000)

ASSY: BV-21235 (1700)

ASSY: BV-21196

+5KVDC FROM FIGURE 5 — 701

GRID2 FROM FIGURE 9

GRID1 FROM FIGURE 9

+5KVGND — 702

+800GND FROM FIGURE 5 — 702

RESEV. HEATER — YEL LEAD

CATHO. HEATER FROM FIGURE 5 — RED LEAD

TO JP1305/12 FIGURE 7A

J801L

+30VDC 12 » 12 +30VDC

HSYNC — 1703 — 1701

TO JP1303/5 FIGURE-7B

T1701 (5, 1, 6, 2, 7, 3)

C1701 1uF 1kV

LSYNC — 1704 — 1702

TO JP1303/6 FIGURE-7B

1001 — L1001 — LN201 FERRITE — 1003 — 801

C1001 0.22 400V

1002 — L1002 — LN202 FERRITE — 1004

C1002 0.22 400V

J201

HIGH — CB101 — K201 (30, 87, 86, 85)

LOW — CB102 — K202 (30, 87, 86, 85)

TO JP1305/11 FIGURE 7A — 1201 +30VDC

EUTPWR — 1206

TO JP1305/10 FIGURE 7A

LN801 — K801 — K803 — CN801 — AN101 4.4K — CN101 5pF — J101 HN — FERRITE

+30VDC — CR802 — CR801 — FROM FIG-9A — RLY1 6 » 6 J801F

CR805 — CR806 — +30VDC — 4 » 4 RLY3 — J801D CN802 — FROM FIG-9A

LN802 — K802 — K804 — CN802 — AN102 4.4K — CN102 5pF — J103 HN — FERRITE

+30VDC — CR802 — CR803 — RLY2 5 » 5 J801E — FROM FIG-9A

CR807 — CR808 — +30VDC — 3 » 3 RLY4 — J801C — FROM FIG-9A

K805

C803 0.01 — C802 0.01 — C801 0.01

+30VDC — CR810 — CR809 — RLY5 7 » 7 J801G — FROM FIG-9A

K806

C805 0.01 — C806 0.01 — C804 0.01

+30VDC — CR812 — CR811 — RLY6 9 » 9 J801I — FROM FIG-9A

802 — 1 » 1 HIGH — J115 E.U.T — 2 » 2 LOW — 3 » 3 GND

JXXXA 1 » 1 — BOARD SIDE — PLUG SIDE

NOTES:

1. UNLESS OTHERWISE SPECIFIED, ALL RESISTORS ARE 2W AND IN OHMS.
2. UNLESS OTHERWISE SPECIFIED, ALL CAPACITORS ARE IN MICROFARADS.
3. ALL SIMILAR NUMBERED CONNECTORS WITH DIFFERENT ALPHA SUFFIXES REFER TO THE SAME CONNECTOR.
4. 24VDC POWER SUPPLY IS FROM FIG-7.

	MODE	RLY1	RLY2	RLY3	RLY4	RLY5	RLY6
POS	DIRECT	0	0	0	1	1	1
	H TO GND	0	1	0	1	0	1
	L TO GND	0	1	1	0	1	0
	H+L TO GND	0	1	0	0	0	0
	H TO L	0	0	0	1	0	0
NEG	DIRECT	0	0	1	0	1	1
	H TO GND	1	0	1	0	0	1
	L TO GND	1	0	0	1	1	0
	H+L TO GND	1	0	1	1	0	0
	H TO L	0	0	1	0	0	0

VELONEX

MODEL V-3113

DISCHARGE/COUPLER SCHEMATIC DIAGRAM

FIGURE 6-10

3113_10.SCH 10/92

RN101
R102 R103
2.2K, 2W EA

RN102
R104 R105
2.2K, 2W EA



CN101
C101 C102
10pF, 1KV EA

CN102
C103 C104
10pF, 1KV EA



CN801
C807 THRU C809, 0.01uF, EA.



RN301
R302 THRU R313, 1M, 2W EA.



CN802
C810 THRU C812, 0.01uF, EA



RN1601
R1602 THRU R1609, 470K, 2W EA.

VELONEX

MODEL V-3113

COMPONENT NETWORKS
SCHEMATIC DIAGRAM

FIGURE 6-11A

3113_11A.SCH 7/91



RN501
R502 THRU R505, 4.3K, 2W EA.



RN502
R506 THRU R509, 4.3K, 2W EA.



RN503
R524 THRU R527, 4.3K, 2W EA.



RN504
R510 THRU R520, 220, 2W EA.



RN505
R528 THRU R532, 510, 2W EA.



CN502
C508 THRU C512, 500pF, 1.5KV EA.
C513 IS 250pF, 1.5KV.



CN503
C515 AND C516, 0.05uF, 500V EA.

VELONEX

MODEL V-3113

COMPONENT NETWORK
SCHEMATIC DIAGRAM

FIGURE 6-11B

3113_11B.SCH 7/91

www.manualsplus.com
1000728